

## Securing element

The CLOUTH DOCTOR CLIP was developed to securely fix the scraper blade in the doctor blade holder.

Take these precautionary measures to prevent injuries.

Doctor blades are sharp by nature - regardless of whether they are new or used.

Therefore, we recommend wearing personal protective equipment.



Wear cut-proof hand protection to protect your hands. The hand protection must fulfil cut protection class 5 in accordance with EN 388 or cut resistance "F" in accordance with EN ISO 13997.

### Safety instructions

- Use the securing element only when the machine is switched off and at a standstill.
- Caution – do not swallow.

## CLOUTH DOCTOR CLIP



### Version, technical data

- Stainless steel
- With and without fixing chain
- Springless design
- High wear resistance
- Quick and easy to attach and remove
- Reusable

### Proper use

The CLOUTH DOCTOR CLIP is used to securely fix the doctor blade in the doctor holder of a paper machine so that it does not move out of the doctor holder, for example, due to the oscillating movement.

### Foreseeable misuse

- Improper use.
- Operation without or with insufficient protective equipment.

### Delivery, storage and transport

- Check the delivery for completeness and external integrity using the delivery note. In the event of transport damage, contact us immediately.



## Securing element

### Operation

By inserting the pin through the opening in the cover plate and the cover plate finger and then folding down the clamp, the CLOUTH DOCTOR CLIP fixes the doctor blade in the doctor blade holder.  
When using the CLOUTH DOCTOR CLIP, care must be taken not to touch the roller or cylinder surface.  
The roller or cylinder diameter should not exceed 2.00 m and the angle of the doctor blade holder should be set to over 20°.  
The springless design of the CLOUTH DOCTOR CLIP is available with and without fixing chain.

### Maintenance and cleaning

The CLOUTH DOCTOR CLIP is maintenance-free, durable and robust due to the use of stainless steel.

### Spare parts

Do not modify the CLOUTH DOCTOR CLIP. Use only original parts, as these ensure safe and trouble-free operation of the product.  
For orders, see contact details.

### Environmental protection

The packaging materials are recyclable. Please dispose of the device in accordance with local regulations/laws.

### Disposal

CLOUTH DOCTOR CLIP that can no longer be used must be disposed of properly in accordance with local regulations/laws.